





# Research and Development Technical Report

H

DELET-TR-81-0381-3

# S

HIGH EFFICIENCY LITHIUM-THIONYL CHLORIDE CELL

Dr. N. Doddapaneni Honeywell Power Sources Center 104 Rock Road Horsham, PA 19044

April 1982

THIRD QUARTERLY for PERIOD 9 OCTOBER 1981 - 8 JANUARY 1982

APPROVED FOR PUBLIC RELEASE: DISTRIBUTION UNLIMITED

Prepared for:

ELECTRONICS TECHNOLOGY AND DEVICES LABORATORY

DCASMA, PHILADELPHIA P. O. BOX 7699 PHILADELPHIA, PA 19101



BERADCOM
US ARMY ELECTRONIC
MONMOUTH, NE US ARMY ELECTRONICS RESEARCH AND DEVELOPMENT COMMAND FORT MONMOUTH, NEW JERSEY 07703

050 82 05 19

HISA-FM 195-78

## NOTICES

#### **Disclaimers**

The citation of trade names and names of manufacturers in this report is not to be construed as official Government indorsement or approval of commercial products or services referenced herein.

### Disposition

Destroy this report when it is no longer needed. Do not return it to the originator.


SECURITY CLASSIFICATION OF THIS PAGE (When Date Entered)	Unclassifed	
REPORT DOCUMENTATION PAGE	READ INSTRUCTIONS BEFORE COMPLETING FORM	
1. REPORT NUMBER 2. GOVY ACCESSION NO	. 3. RECIPIENT'S CATALOG NUMBER	
DELET-TR-81-0381-3		
4. TITLE (and Sublitio)	5. TYPE OF REPORT & PERIOD COVERED	
	10-9-81 to 1-8-82	
High Efficiency Lithium-Thionyl Choride Cell	Third Quarterly	
	6. PERFORMING ORG. REPORT NUMBER	
7. AUTHOR(s)	8. CONTRACT OR GRANT NUMBER(#)	
N. Doddapaneni	PAAK20-81-C-0381	
9. PERFORMING ORGANIZATION NAME AND ADDRESS	10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS	
Honeywell Power Sources Center	1	
104 Rock Road	1L162705ΛΗ94-11-211	
Horsham, Pa. 19044		
11. CONTROLLING OFFICE NAME AND ADDRESS	12. REPORT DATE April 1982	
U.S. Army Elct Tech & Dvcs Laboratory ATTN: DELET-PR	13. NUMBER OF PAGES	
Fort Monmouth, NJ 07703	37 pages	
14. MONITORING AGENCY NAME & ADDRESS(If different from Controlling Office)		
DCASMA, Philadelphia	Unclassified	
P.O. Box 7699		
Philadelphia, Pa. 19101	154. DECLASSIFICATION/DOWNGRADING SCHEDULE	
16. DISTRIBUTION STATEMENT (of this Report)		
Approved for Public Release:		
Distribution Unlimited		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, If different	rom Report)	
1		
18. SUPPLEMENTARY NOTES		
1		
i		
!		
10 MEN WORDS (CO. M. C.		
19. KEY WORDS (Continue on reverse side it necessary and identify by block numb		
Thionyl chloride, lithium, high discharge rates, low temperatures, catalysis, cyclic voltammetry		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number	nr)	
During the third quarter, cathode optimization with respect to specified		
variables was completed. Performance evaluation of optimized cathodes		
variables was completed. Performance evaluation of optimized cathodes at 32 and 75 recoved both catalyst B and C (FePc) and (CoPc) minimized		
the electrode overpotential.		
Plats of 1-1 vs W 1/2 from rotating disc ele	strode studies produced	

Unclassified

# TABLE OF CONTENTS

		Page
I	INTRODUCTION	1
II	EVALUATION OF CATHODE OVERPOTENTIAL	3
III	KINETIC AND MECHANISTIC STUDIES	19
IV	AC IMPEDANCE MEASUREMENTS .	24
V	SUMMARY AND FUTURE WORK	33
	DISTRIBUTION	35

DTIG COPY INSPECTED



# LIST OF FIGURES

		Page
1.	Effect of Cathode Variables on Li/SOC12 Cell Life with 50% SAB in 1.5M LiAlClu/SOC12 at -20°F	4
2.	Same, except 100% SAB	5
3.	Same, except 5% (CoPc) <sub>n</sub> .	6
4.	Effect of Carbon Substrates on the Li/SOCl <sub>2</sub> Cell Discharge Time in 1.5M LiAlCl <sub>4</sub> /SOCl <sub>2</sub> at -20°F	. 7
5.	Effect of Cathode Thickness on Discharge Characteristics of Li/SOCl <sub>2</sub> Cell, etc.	9
6.	Effect of Cathode Thickness on Discharge Performance Characteristics	10
7.	Effect of CAthode Thickness on Discharge Performance, etc.	11
8.	Effect of Cathode Thickness on Discharge Characteristics, etc.	` 12
9.	Polarization Characteristics at 75°F	14
10.	Discharge Characteristics at 10 mA/cm <sup>2</sup> and 75°F	15
11.	" " 20 mA/cm <sup>2</sup> " . "	16
12.	" " 10 mA/cm <sup>2</sup> and 32°F	17
13.	" 20 $\mathrm{mA/cm^2}$ and $32^{\circ}\mathrm{F}$ .	18
4.	Plot of 1/ip VS 1/w From the Rotating Disc Data	21
15.	N N N N N N N N N	22
6.	tr # 11 fr '11 fr fr fr	23
7.	Impedance of Stress Annealed Pyrolytic Graphite Electrode	27
8.	17 tr fr 17 tr 18	28
9.	11 11 11 11 11	29
.0.	TT TE BE 15 39 39	30
1.	TT 10 00 00 00 00	31
2.	TT 11 11 11 11 11 11	32

#### I. INTRODUCTION

The Li/SOCl<sub>2</sub> system (1-4) has the potential to be one of the best primary batteries having combined characteristics of high rate and high energy density capability, long shelf-life and wide operating temperature range. However, many of these advantages have not been fully derived. The operating capabilities of Li/SOCl<sub>2</sub> batteries are limited, to a large extent, by the Teflon bonded porous carbon electrode commonly used as a cathode. Cell failure at high discharge rates and/or low operating temperatures has, as one of its main causes, the high cathodic overpotential resulting from non-uniform current distribution over the porous electrode.

The porous carbon cathode, where the reduction of SOCl<sub>2</sub> occurs, has a limited capacity for retaining solid lithium chloride as it precipitates in the pore structure. As the lithium chloride accumulates, the porosity of the electrode is reduced to where mass transport, particularly of the cathode depolarizer, can no longer be maintained at a rate sufficient to support the required current density. When this happens, polarization becomes excessive and denotes the end of useful battery life.

At high rate discharges and low operating temperatures, the cathode polarization problem becomes very severe. Analysis of the porous electrode shows that, at high rate discharges, only a small part of the available surface participates in the electrochemical process.

Cathode polarization and the reaction zone thickness strongly depend on electrode reactions, cathode thickness and composition. Minimization of the effects of these variables on overpotential is essential in order for Li/SOCl<sub>2</sub> batteries to be viable electrochemical devices for many of the high rate/low temperature applications.

The objectives of this program, therefore, are to:

- Evaluate the polarization characteristics of Teflon-bonded porous carbon cathodes.
- Improve cathode performance at high discharge rates and low operating temperatures.

Polarization characteristics will be determined as a function of cathode thickness, composition and density, applied current density and temperature (-40°F to 75°F). Several experimental techniques such as half-cell measurements, discharge performance characteristics, impedance measurements, and cyclic voltammetry studies will be employed to evaluate the extent of each variable's contribution to the cathode polarization.

Improvement in cathode performance will be made by the use of electrocatalysis. Three catalysts employed in this program have shown marked improvements in both cell voltage and cathode capacity. They were,

Catalyst A = Cobalt Phthalocyanine Monomer, CoPc

Catalyst B = Iron Phthalocyanine Monomer, FePc

Catalyst C = Polymeric Cobalt Phthalocyanine, (CoPc)<sub>n</sub>

During the first quarter of this program (6), we examined:

- a) The overpotential of cathodes with and without Catalyst B and C, over a temperature range of -40 to 75°F,
- b) The effects of catalysts and temperatures on cyclic voltammograms in LiAlCl<sub>4</sub>/SOCl<sub>2</sub> electrolyte solutions.
- c) The effects of operating temperatures (-40 to 75°F on the conductivity and viscosity of the electrolyte solutions (LiAlCl<sub>4</sub>/SOCl<sub>2</sub>).

During the second quarter (7), we completed the overpotential measurements at -20 and -40°F on our present baseline cathodes with and without catalysts. These cathodes contained 5% Teflon binder and had a thickness of 0.020 inch. Furthermore, we systematically evaluated the effect of cathode thickness, amount of Teflon binder, and cathode substrates on cathode performance.

During this reporting period, we examined:

- a) Polarization with respect to cathode variables.
- b) Performance of optimized cathodes.
- c) Cyclic voltammograms at rotating disc electrodes.
- d) AC impedance measurements of porous electrodes.

<sup>\*</sup> Patents pending

#### II. EVALUATION OF CATHODE OVERPOTENTIAL

#### A. CATHODE PERFORMANCE IMPROVEMENTS


#### 1. Introduction

The effect of carbon substrate, density and thickness of porous carbon cathodes on the overall performance of  $\text{Li/SOCl}_2$  cells at  $0^{\circ}\text{F}$  and  $75^{\circ}\text{F}$  was reported in the second quarterly report  $\binom{7}{7}$ . During this period, the effect of cathode variables at -20 and -40°F were evaluated using catalyst C (CoPc)<sub>n</sub>. At these temperatures, the FePc catalyst was found to contribute severe voltage delay. Nevertheless, significant improvement in overall performance of  $\text{Li/SOCl}_2$  cells was still achieved with this catalyst throughout the operating temperatures and discharge current rates studied.


#### 2. Electrochemical Cell Performance

Laboratory cells were built and tested with cathodes having several variables. Low temperature tests (-20 and  $-40^{\circ}$ F) were conducted after allowing the cells to stand at operating temperature for 30-60 minutes. Even with the use of distilled thionyl chloride solvent (Mobay Chemicals), severe voltage delays at discharge rates of 5 or 10 mA/cm<sup>2</sup> were observed. To overcome this problem and thus allow catalyst C to be evaluated for rate improvement, the cells were subjected to a small discharge current  $(0.1 \text{ mA/cm}^2)$  during their stand time period.


Figures 1 through 3 show the effect of cathode thickness and density (as varied by composition) on discharge time. Both of these cathode variables affected cell life. The influence on discharge time by the cathode variables studied are compared in Figure 4. Even though discharge time increased with cathode thickness, the increase was not proportional to the thickness. Therefore, it should be noted that the reaction zone thickness depends strongly on cathode thickness, discharge rate and operating temperature. The lithium chloride deposition in the carbon pores might be creating the resistive film that is responsible for cathode polarization and hence cell life.




Effect of Cathode Variables on L1/SOC1<sub>2</sub> Cell Life with 50% SAB in 1.5M L1AlC1 $_{\rm u}/{\rm SOC1_2}$  at  $-20^{\rm O}{\rm F}$ . Figure 1.



Effect of Cathode Variables on L1/SOCl\_2 Cell Life with 100% SAB in 1.5M L1AlCl\_4/SOCl\_2 at -20  $^{\rm F}$ Figure 2.



Effect of Cathode Variables on Li/SOCl $_2$  Cell Life with 5% (CoPc)  $_{\rm n}$  Catalyzed Cathodes in 1.5M LiAlCl $_{\rm u}/{\rm SOCl}_2$  at  $-20^{\rm F}{\rm F}$ Figure 3.



Effect of Carbon Substrates on the L1/SOCl $_2$  Cell Discharge Time in Figure 4.

The effect of cathode thicknesses on the overall discharge characteristics of Li/SOCl<sub>2</sub> cells are shown in Figures 5 through 8 for various cathode compositions. With increased Teflon content in the cathode, the discharge time, in general, decreases, but cell voltage remains constant, within experimental error, for each cathode thickness. Catalyst doping (Figure 7 and 8) can be seen to improve both cell voltage and discharge time.

The discharge performance of  $\text{Li/SOCl}_2$  at  $-40^{\circ}\text{F}$  showed severe cell polarization with and without catalyst. The discharge characteristics were similar to the reported results (7).

#### B. PERFORMANCE OF OPTIMIZED CATHODES

#### 1. Introduction

The systematic evaluation of baseline cathode performance since the start of this program has resulted in the optimization of cathode(s) for Li/SOCl<sub>2</sub> cells. The optimized cathodes contain (by weight):

#### a) Baseline Cathode


- 95% 100% compressed-grade Shawinigan acetylene black carbon substrate, (100% SAB).
- 5% Teflon-6 binder

# b) <u>Catalyzed Cathode</u>, (CoPc)

- 5% polymeric cobalt phthalocyanine
- 90% 100% SAB
- 5% Teflon-6

#### c) Catalyzed Cathole, FePc

- 95% 100 SAB
- 5% Teflon-6
- 2-5 mg of FePc/cc of electrolyte (both neutral and acidic electrolyte)



Effect of Cathode Thickness on Discharge Characteristics of 1.7 i.5M LiAlClu/SOCl\_2 Electrolyte Pigure 5.






Figure 6. Effect of Cathode Thickness on Discharge Performance Characteristics of L1/SOC12 Cells with 1.5M LiAlClu/SOC12 Electrolyte (10% PIFE).



Effect of Cathode Thickness on Discharge Performance of L1/SOCl2 with Catalyzed Cathode Containing 5% Teflon Binder in 1.5M LiAlCl4/SOCl2 Figure 7.




Effect of Cathode Thickness on Discharge Characteristics of Li/SOCl2 Cells with Catalyzed Cathode Containing 10% Teflon Binder in 1.5M LiAlClu/SOCl<sub>2</sub> Electrolyte. Pigure 8.

#### 2. Laboratory Cell Performance


The laboratory cell design and the description of cell components used in the evaluation of cathode polarization presented here have been described elsewhere (6). Both half-cell measurements and cell discharge performance were made on the optimized cathodes at 75 and 32°F. Cathode thickness in all cases was 0.020 inch.

In Figure 9, the polarization characteristics of Li/SOCl<sub>2</sub> cells with 3 different cathodes are compared. With the catalyzed cathodes, cathode polarization decreased; the highest catalytic effect was achieved with FePc. The decrease in polarization is attributed to elementary processes taking place at the cathode (activation polarization). The effect of FePc doping further contributed to the higher cell limiting current. Therefore, it is assumed that the FePc catalyst not only enhanced the rate of electrochemical reduction of thionyl chloride but also modified the reaction mechanisms. This could potentially lead to a safer Li/SOCl<sub>2</sub> cell/battery.

The discharge performance of Li/SOCl<sub>2</sub> cells with and without catalyzed cathodes contributed to both high voltage and longer discharge time, as shown in Figures 10 through 13. FePc catalyzed cathodes showed the smallest cell voltage loss and the longest discharge life. The cell life increased by a factor of 2 over the uncatalyzed cathodes with FePc at 32 and 75°F.




Pigure 9. Polarization Characteristics of Li/SOCl2 Cells at 75°F.



Discharge Characteristics of L1/SOCl2 Cells at 10 mA/cm2 and 75°F. Figure 10.

Discharge Time, minutes



Discharge Time, minutes

Figure 11. Discharge Characteristics of Li/SOCl2 Cells at 20 mA/cm2 and 75°F.





Figure 12. Discharge Characteristics of Li/SOCl2 Cells at 10 mA/cm2 and 32°F



Discharge Time, minutes

Figure 13. Discharge Characteristics of Li/SOCl2 Cells at 20 mA/cm2 and 32°F.

#### III KINETIC AND MECHANISTIC STUDIES

The studies of electrode kinetics are important in understanding both the intermediate Li/SOCl<sub>2</sub> reaction products and the reaction mechanism since these two important factors contribute to battery safety and performance. Cyclic voltammetric studies in 1.0M LiAlCl<sub>4</sub>/SOCl<sub>2</sub> solutions at various cathode surfaces indicate (6) that the system is diffusion controlled. However, it should be noted that the reaction products which are strongly adsorbed on the cathodes, and the diffusion limitations, might have contributed to the current peak heights in cyclic voltammograms. Therefore cyclic voltammetric studies were carried out at a rotating disc electrode.

Cyclic voltammograms were obtained at a glassy carbon electrode (0.458 cm<sup>2</sup>). An ASR rotator, manufactured by Pine Instrument Company, was used to rotate the disc electrode. Cyclic voltammograms were generated using PAR electrochemistry system Model 170.

As a first order reaction mechanism, the experimental currents in a rotating disk study are related to the rotation rate  $\omega$  (in rpm) by the equation

$$\frac{1}{\mathbf{i}} = \frac{1}{\mathbf{i}_k} + \frac{1}{B\sqrt{\omega}} \tag{1}$$

where  $i_{\mathbf{k}}$  is the kinetic current and B is a constant:

$$B = \sqrt{\frac{2\pi}{60}} \qquad \text{n'F } v^{1/2} C_0 \left[ 0.621 \text{ s}^{-2/3} \left( 1 + 0.298 \text{ s}^{-1/3} + 0.145 \text{ s}^{-2/3} \right) \right]$$
 (2)

where

ν = kinematic viscosity

F = The Faraday constant

n = The number of electron's per mole of electroactive species
(SOCl<sub>2</sub> in our case)

 $C_0$  = The concentration of SOCl<sub>2</sub> in moles/cm<sup>3</sup>

S = v/D, where D = diffusion coefficient

Figure 14 shows the plots of  $i_p^{-1}$  vs  $\omega^{-1/2}$  from the rotating disc data for SOCl<sub>2</sub> reduction at glassy carbon electrode (0.458 cm<sup>2</sup>) in 1.5M LiAlCl<sub>4</sub>/SOCl<sub>2</sub> with and without FePc catalyst. At limiting currents, i.e., peak heights ( $i_p$ ), the currents usually correspond to pure diffision control for the SOCl<sub>2</sub> reduction. However, the plots indicate that the kinetic currents (intercepts) contribute to the limiting currents at 100 mv/second scan rate. Furthermore, in the presence of FePc catalyst, the kinetic current contribution to the limiting currents increases by 2.5 times (from 25.24 mA/cm<sup>2</sup> to 63.1 mA/cm<sup>2</sup>). The  $i_k$  values decrease with decreasing scan rate in both cases. The  $i_p^{-1}$  vs  $\omega^{-1/2}$  plots from the rotating disc data obtained at different scan rates in FePc added to 1.5M LiAlClR/SOCl<sub>2</sub> electrolyte show (Figure 15) decreased kinetic currents with decreasing scan rate.

From the slopes of the straight lines in Figure 14, the B value can be calculated. For a similar reaction mechanisms, the slopes should be equal as the changes in the values of parameter in equation 2 are minimal with the addition of FePc catalyst to the electrolyte. However, in the presence of FePc catalyst, the B value increases from 0.467 to 0.633. This increase could be attributed to the modification in the overall reaction mechanism as follows:


At baseline cathode:

$$SOC1_2 + 2e \longrightarrow 2 C1 + 1/2 S0_2 + 1/2 S$$
 (3)


At FePc catalyzed cathode:

$$SOCl_2 + 2-1/2 = -2 Cl + 1/4 (S_2O_4)^{-2} + 1/2 S$$
 (4)


Plots of  $i_p^{-1}$  vs  $\omega^{-1/2}$  yield parallel straight lines at potentials anodic to the maximum (Figure 16), indicative of a first order process on SOCl<sub>2</sub>. Deviation from parallel straight lines at more anodic potential could be due to changes in the reaction mechanisms. Further studies are needed to more fully understand the phenomenon.



Plot of  $1/1_D$  VS  $1/\sqrt{\omega}$  From the Rotating Disk Data for Glassy Carbon Electrode (0.458 cm<sup>2</sup>) in 1.5M LiAlClu/SOCl<sub>2</sub> at Room Temperature, (Scan Rate 100 mV/second) Figure 14.



Plots of 19 1 VS w -1/2 From the Rotating Disc Data for Glassy Carbon Electrode (0.458 cm<sup>2</sup>) in 1.5M LiAiClu/SOCl<sub>2</sub> + PePc at Different Scan Rates (--- 100 mV/seconds, --- 1 mV/seconds) Pigure 15.



Plot of 1-1 VS  $\omega^{-1/2}$  at Different Potentials From the Rotating Disc Data for Glassy Carbon Electrode (0.458 cm<sup>2</sup>) in 1.5M LiAlCl<sub>4</sub>/SOCl<sub>2</sub> at RT. Figure 16.

#### IV AC IMPEDANCE MEASUREMENTS

#### A. INTRODUCTION

Physical and chemical processes taking place at the electrode interface influence the overpotential of an electrode system. There are three types of processes which contribute to the total electrode overpotential; they are:

- a) activator overpotential
- b) concentration overpotential
- c) ohmic overpotential

All three types of overpotential contribute to cathode polarization in a Li/SOCl<sub>2</sub> system. The magnitude of each type depends on the operating current density, temperature, electrolyte conductivity and viscosity. In order to minimize the overall cathode potential, it is important to understand and evaluate each type.

Two non-steady state measurement techniques, galvanostatic single current pulse and AC impedance measurements are generally used to determine the type and magnitude of overpotentials. Recent successful AC impedance measurements studies (8,9) of lithium anodes prompted us to utilize this technique for porous electrode.

Alternating current impedance measurements are attractive to kinetic reaction studies, but the interpretation of experimental data obtained on a porous electrode can cause substantial complications, especially when adsorption and desorption processes are involved. However, recent advances in electronics have enabled the acquisition of a complete impedance spectrum within minutes by the use of the fast Fourier transform (FFT) algorithm, which allows Fourier analyses to be carried out readily upon complex input signals.

The theory of electrochemical impedance measurements of porous electrodes is very complex and will not be given here. Basically, a spectrum analyzer determines

impedance spectra by noise response impedance analysis; a white noise source generated by an analyzer is delivered to the cell and the current response is subjected to FFT analysis. The frequency dependent impedance and phase angle are displayed in the CRT and can be recorded easily.

#### B. EXPERIMENTAL

AC impedance data were obtained at Sandia National Laboratories using a Hewlett Packard 3722A noise generator and a PAR Potentiostat 173.A Hewlett-Packard 9845T desk top computer was used to reduce the data. Impedance measurements at both steady state and dynamic conditions were made over the frequency range of 0.01 Hz to 1000 Hz.

The electrochemical cell consisted of a carbon electrode and a platinum counter electrode. Impedance measurements of the cathodes were made with and without iron phthalocyanine catalyst in 1.5M LiAlCl<sub>4</sub>/SOCl<sub>2</sub> electrolyte (3 mg FePc cc of electrolyte). Initial impedance experiments of baseline porous carbon electrodes with and without catalyst revealed that the electron transfer process was extremely slow at open circuit voltage and the impedance spectrum had a very large diamter. In order to minimize problems associated with high surface area porous electrodes, a stress annealed pyrolytic graphite electrode (A = 0.178 cm<sup>2</sup>) was used.

#### C. RESULTS

In Figures 17 and 18, the complex impedance of carbon electrodes with and without FePc catalyst respectively, in 1.5M LiAlCl<sub>4</sub>/SOCl<sub>2</sub> electrolyte are given. The diameter of the semicircle represents the Faradaic resistance if the capacitance value is small. For a diffusion controlled reaction, a straight line with a phase angle of 45° is usually obtained in the complex impedance. For a porous electrode the phase angle should be 22°.

The impedance of carbon electrodes in 1.5M LiAlCl<sub>4</sub>/SOCl<sub>2</sub> with and without FePc catalyst shows a semicircle with a large diameter. The diameter decreases with FePc catalyst. Still, very high resistance due to charge transfer process exists,

<sup>\*</sup> Experiments were carried out by Dr. Frank M. Delnick of Sandia National Laboratories

which is indicative of very slow reaction rates at open circuit voltage. The open circuit potentials vs platinum electrode were -0.322V and -0.511V for cathodes with and without FePc catalyst.

Impedance measurements were made on catalyzed cathodes under dynamic conditions. Figures 19 through 21 show the complex impedance at discharge rates of 34, 112 and 675  $\mu$ A/cm<sup>2</sup>. The current rates remained constant at 34 and 112  $\mu$ A/cm<sup>2</sup> throughout the experimented time (30 minutes at each experiment); however the discharge current, 675  $\mu$ A/cm<sup>2</sup> decreased slowly with time (675  $\mu$ A/cm<sup>2</sup> to 450  $\mu$ A/cm<sup>2</sup>). At 34 and 112  $\mu$ A/cm<sup>2</sup> discharge, the charge transfer resistance decreased but the reaction rates were still very slow. At 675  $\mu$ A/cm<sup>2</sup>, the reaction is completely diffusion controlled as shown in Figure 21 by a straight line with a phase angle of 42°. Furthermore, when the impedance measurements were made at open circuit voltage after passing 675  $\mu$ A/cm<sup>2</sup> current for nearly 30 minutes, as shown in Figure 22, the reaction is still diffusion controlled.

Additional experiments are needed to understand and establish various resistances (ionic, faradaic, etc.) which contribute to the cathode overpotential.




Figure 17. Impedance of Stress Annealed Pyrolytic Graphite Electrode (0.178 cm<sup>2</sup>) in 1.5M LiAlCl<sub>4</sub>/SOCl<sub>2</sub> Containing FePc Catalyst.




Figure 18. Impedance of Stress Annealed Pyrolytic Graphite Electrode (0.178 cm<sup>2</sup>) in 1.5M LiAlCl<sub>4</sub>/SOCl<sub>2</sub> Electrolyte at 75°F.




Figure 19. Impedance of Stress Annealed Pyrolytic Graphite Electrode (0.178 cm<sup>2</sup>) at a Discharge Rate of 34 µA/cm<sup>2</sup> in 1.5M LiAlCl<sub>4</sub>/SOCl<sub>2</sub> + FePc.




Figure 20. Impedance of Stress Annealed Pyrolytic Graphite Electrode (0.178 cm<sup>2</sup>) at a Discharge Rate of 112 μA/cm<sup>2</sup> in 1.5M LiAlCl<sub>4</sub>/SOCl<sub>2</sub> + FePc.




Figure 21. Impedance of Stress Annealed Pyrolytic Graphite Electrode (0.178 cm<sup>2</sup>) at a Discharge Rate of 675 μA/cm<sup>2</sup> in 1.5M LiAlCl<sub>4</sub>/SOCl<sub>2</sub> + FePc.




Figure 22. Impedance of Stress Annealed Pyrolytic Graphite Electrode (0.178 cm $^2$ ) at Open Circuit Voltage (After 30 minutes at 675  $\mu$ A/cm $^2$  discharge) in 1.5M LiAlCl $_4$ /SOCl $_2$  + FePc.

#### V. SUMMARY AND FUTURE WORK

During the third quarter, cathode optimization with respect to specified variables was completed. Performance evaluation of optimized cathodes at 32 and  $75^{\circ}F$  showed both catalyst B and C [FePc and (CoPc)<sub>n</sub>] minimized the electrode overpotential.

Plots of  $i_p^{-1}$  vs  $\omega^{-1/2}$  from rotating disc electrode studies produced parallel straight lines, indicative of a first order reaction mechanism. The slope of the straight line decreased with FePc catalyzed cathodes. This could indicate a change in reaction mechanism.

AC impedance measurements of a carbon electrode indicated extremely slow charge transfer and at high discharge rates, the rates were purely diffusion controlled.

During the last quarter of the program, we will carry out:

- Performance evaluation of optimized cathodes at 0 and -20°F.
- Continued rotating disc electrode studies at low temperatures.
- Writing of final report.

#### REFERENCES

- 1. W. K. Behl, J. A. Christopulos, S. Ramirez and S. Gilman, J. Electrochem. Soc. 120, 1619 (1973).
- J. J. Auborn, K. W. French, S. I. Lieberman, V. K. Shah and A. Heller,
   J. Electrochem. Soc. 120, 1613 (1973).
- 3. G. E. Blomgren, V. Z. Leger, T. Kalnoki-Kis, M. L. Kronenberg and R. J. Brodd, in "Power Sources", J. Thomson, Editor, p. 583, Academic Press, (1979).
- 4. A. N. Dey, Thin Solid F 1ms, 43, 131 (1977).
- 5. N. Doddapaneni, Extended Abstracts of the Electrochemical Society, Vol. 81-1, 218-219 (1981).
- 6. N. Doddapaneni, High Efficiency Lithium-Thionyl Chloride Cell, First Quarterly Report, DELET-TR-81-0381-1. Honeywell Power Sources Center, October 1981.
- 7. N. Doddapaneni, High Efficiency Lithium-Thionyl Chloride Cell, Second Quarterly Report, DELET-TR-81-0381-2, Honeywell Power Sources Center, January 1982.
- 8. J. Phillips, J. C. Hall and H. F. Gibbard, Extended Abstracts of Electrochem. Soc., Vol. 80-2, 165-167, (1980)
- 9. F. M. Delnick and C. D. Jaeger, Extended Abstracts of Electrochem. Soc. Vol. 81-2, 223-225 (1981).
- 10. V. G. Levich, "Physiochemical Hydrodynamics", Prentice Hall, Englewood Cliffs, NJ (1962).

# DISTRIBUTION LIST

Defense Technical Info Ctr		Commander .	
ATTN: DTIC-TCA	•	US Army Electronics R&D Command	
Cameron Station (Bldg 5)		Fort Monmouth, NJ 07703	
Alexandria, VA 22314	(12)	•	
		DELET-DD	(1)
Cdr, Naval Surface Weapons Ctr		DELET-DT	(1)
White Oak Laboratory		DELSD-L (Library)	(1)
ATTN: Library, Code WX-21		DELSD-L-S (Stinfo)	(2)
Silver Spring, MD 20910	(1)	DELET-PR (S. Gilman)	(20)
Commandant, Marine Corps		NASA Scientific & Tech, Info	
HQ, US Marine Corps		Facility	
ATTN: Code LMC, INTS (In Turn)		Baltimore/Washington Intl Airpt	
Washington, DC 20380	(1)	PO Box 8757, MD 21240	(1)
Rome Air Development Center		CMDR, MICOM	
ATTN: Documents Library (TSLD)		ATTN: DRCPM-HDE	
Griffiss AFB, NY 13441	(1)	Redstone Arsenal, AL 35809	(1)
AFGL/SULL		Foote Mineral Company	
S-29		Route 100	
HAFB, MA 01731	(1)	Exton, PA 19341	
		ATTN: Dr. H. Grady	(1)
HQDA (DAMA-ARZ-D/Dr. F.D. Verdera	me)		
Washington, DC 20310	(1)	Eagle-Picher Industries, Inc.	
	•	Electronics Division	
Cdr, Harry Diamond Laboratories		P.O. Box 47	
ATTN: Library		Joplin, Missouri 64801	
2800 Powder Mill Road		ATTN: Mr. Robert L. Higgins	(1)
Adelphia, MD 20783	(1)		
<del>-</del>		Yardney Electric Company	
Director		82 Mechanic Street	
US Materiel Sys Anal Actv		Pawcatuck, CT 06379	
ATTN: DRXSY-T		ATTN: Technical Library	(1)
Aberdeen Prov Grnd, MD 21005	(1)		• •
•	• •	Duracell International, Inc.	
Cdr, USA Signals Warfare Lab		Northwest Industrial Park	
ATTN: DELSW-OS		Burlington, MA 01803	
Vint Hill Farms Station		ATTN: Dr. A.N. Dey	(1)
Warrenton, VA 22186	(1)	,	(-,
	\~ <b>,</b>	Exxon Research & Engineering Co.	
Commander		Corporate Research Laboratory	
USA Mobility Eqp Res & Dev Cmd		Linden, NJ 07036	
ATTN: DRDME-R		ATTN: Dr. R. Hamlen	(1)
Fort Belvoir, VA 22060	(1)		(-)
•	• •	Argonne National Laboratories	
Cdr, Harry Diamond Labs		9700 South Cass	
ATTN: DELHD-CO,TD (In Turn)		Argonne, IL 60439	
2800 Powder Mill Road		ATTN: Dr. E.C. Gay	(1)
Ade1nh1e MD 20783	(1)	•	<del>-</del>

-	•	GTE Laboratories, Inc. 520 Winter Street Waltham, MA 02154	
		ATTN: Dr. Ronald McDonald	(1)
General Motors Corp.		Electrochimica	
Research Laboratories		2485 Charleston Road	
General Motors Technical Center		Mountain View, CA 94040	
12 Mile and Mounds Roads		ATTN: Dr. Eisenberg	(1)
Warren, MI 48090			
ATTN: Dr. J.L. Hartman	(1)	Energy Storage & Conversion De TRW Systems	ept.
Union Carbide Corporation		One Space Park	
Parma Research Center		Redondo Beach, CA'90278	•
P.O. Box 6116		ATTN: Dr. H.P.Silverman	(1)
Cleveland, OH 44101	(1)		
		Sanders Associates, Inc.	
Duracell International, Inc.		24 Simon Street	
S. Broadway		Mail Stop NSI-2208	
Tarrytown, NY 10591		Nashua, NH 03060	
ATTN: J. Dalfonso	(1)	ATTN: J. Marshall	(1)
			<b>\-</b> /
North American Rockwell Corp.		Power Conversion, Inc.	
Atomics Internation Division		70 MacQuesten Pkwy	•
Box 309	•	Mount Vernon, NY 10550	
Canoga Park, CA 91304		ATTN: Stuart Chodosh	(1)
ATTN: Dr. L. Heredy	(1)	Min. Didair ollogooli	(-/
	<b>\-</b> /	Portfolio Manager	
General Electric Research &		Hooker Chemicals & Plastics Co	rn .
Development Center		M.P.O. Box 8	-P.
P.O. Box 8		Niagara Falls, NY 14302	(1)
Schenectady, NY 12301		Mragara raits, Mt 14302	(1)
ATTN: Dr. Stefan Mitoff	(1)	G207	
	1-7	S.R.I.	
University of California		Menlo Park, CA 94025	
Department of Science & Research		ATTN: Dr. Leonard Nanis	(1)
Santa Barbara, CA 93100		Alth: Dr. Deougla Mants	(1)
ATTN: Dr. J. Kennedy	(1)	Bell Laboratories	
mann pro de namedy	(-)	600 Mountain Avenue	
Gulton Industries, Inc.			
Metuchen, NJ 08840		Murray Hill, NJ 07974	17 (1)
ATTN: Mr. S. Charlip	(1)	ATTN: Dr. J.J.Auborn, Rm 1A-3	17 (1)
min. In. S. Charrip	<b>'1</b> )	Int Dungulaton Labouatoms	
INCO Research and Development		Jet Propulsion Laboratory	
Center		4800 Oak Grove Drive	
Sterling Forest		Pasadena, CA 91103	
Suffern, NY 10901		ATTN: Mr. Harvey Frank	<b>/11</b>
	(1)	Mail Stop 198-220	(1)
ATTN: Nehemiah Margalit	(1)		
N/mananan		Naval Surface Weapons Center	
Director		White Oak Laboratory, Code R-3	3 (M/S AU26)
Propulsion and Power Division		Silver Spring, MD 20910	445
Mail Code EP5	*	ATTN: Dr. D. Ernst	(1)
NASA-Johnson Space Center			0440
Houston, Texas 77058	/13	Energy Conversion Branch Code	
ATTN: Mr. B. J. Bragg	(1)	Naval Underwater Systems Cente Newport Laboratory	r
		Newport, RI 02840	
¥ .		ATTN: Mr. J. R. Moden	(1)

NASA Lewis Research Center Mail Stop 6-1 21000 Brookpark Road Cleveland, OH 44135		Dr. Jerry J. Smith ONR Chemical Program Arlington, VA 22217 (1)
ATTN: Dr. Stuart Fordyce	(1)	Saft Corporation of Aermica 711-A Industrial Blvd. P.O. Box 1284 Valdosta, GA 31601
		ATTN: Mr. Lou Adams (1)
EIC, Inc. Newton, MA 02158		Gould Laboratories-Energy Research 40 Gould Center Rolling Meadows, IL 60008
ATTN: S.B. Brummer	(1)	ATTN: Dr. J. Hall. (1)
Altus Corp. 440 Page Mill Road Palo Alto, CA 94306 ATTN: Douglas Glader	(1)	Electrochem Industries (E-I) Inc. 9990 Wehrle Drive Clarence, NY 14031 ATTN: Dr. C. Liang (1)
	• •	911 01 2125 (1)
MS 488 NASA Langley Research Center Hampton, VA 23665		GTE Laboratories Incorporated 40 Sylvan Road Waltham, MA 02254
ATTN: J. Bene	(1)	ATTN: Dr. C. Shlaiker (1)
Research and Development Divis The Gates Rubber Co. 999 S. Broadway	ion	Harvey N. Seiger Associates 8 Beacon Hill Drive Waterford, CT 06385
Denver, CO 80217 ATTN: Mr. Eddie T. Seo	(1)	ATTN: Harvey N. Seiger, Ph.D. (1)
Mail Stop 8C-62 Boeing Aerospace Company P.O. Box 3999 Seattle, WA 98124	(4)	•
ATTN: Mr. Sidney Gross	(1)	•
Honeywell Technology Center 10701 Lyndale Avenue, South Bloomington, MN 55420	<b></b>	•
ATTN: Dr. H.V. Venkatasetty	(1)	
Jet Propulsion Laboratory M.S. 198-220		•
4800 Oak Grove Drive		🖈
Pasadena, CA 91103 ATTN: Mr. Aiji Uchiyama	(1)	Õ
Naval Surface Weapons Center White Oak Laboratory, Code R-3	3	<b>⊙</b>
Silver Spring, MD 20910 ATTN: Dr. Frank Bis	(1)	0
MINI DI. FIERE DIS	(1)	35 A
		O
		Tables
		• 0•

37

